






INSTRUCTIONS FOR BEAD BAZOOKA – GB5MA



Ref. No.	Part No.	Description
1.	12910M5	5G. MIS Air Tank
2.	12913M2	2" Single Barrel
3.	12927M	Plastic Protector-Red
4.	12912B2	2" Lock Nut (50.8 mm)
5.	12914B	1.5" Pressure Gauge 10Bar
6.	12930M	F 1/4" x3 & M 1/4"x1 Connector
7.	12916B	1/4"PT Intake Valve (6.35 mm)
8.	12917B	Safety Valve Max 10Bar
9.	12932M	Tommy Gun Grip
10.	12911-2	3" x 2" connector
11.	12950	2" W 1.7 O-Ring
12.	12951	2" Wide Screw
13.	12952	2" W 5.3 O-Ring
14.	12953S	Short 2" Piston-30mm
15.	12954	2" W 3.5 O-Ring
16.	12955	Stainless Spring
17.	12956	2" W 11.2 O-Ring
18.	12919BL	Switch Valve-Long
19.	12919BS	Safety Trigger Caps
20.	12927	Universal Connector
21.	12937-A	2" RAR Auto Valve
22.	12958S	Short 2" Piston-30mm w/ O-Ring


- It is best to use clean / filtered compressed air to fill all Bead Bazooka® / Bead Booster® inflation tools
- Unfiltered or unclean compressed air may poor performance and shorten the life of the product.
- Gaither recommends this Bead Booster® tank be replaced after 5 years

GAITHER GB-5MA



DO NOT PLACE THE BARREL FIRMLY AGAINST THE RIM,

but instead it should be held 2-3" away from the wheel flange when firing for better overall lift













2) The 2" Single Barrel (b) must be installed into the large release opening shown in the above diagram. Install and secure lock nut so that the


2" Single Barrel is securely tightened.

GAITHER GB-5MA

Gaither's #12937-A Valve Repair kit

		BBVRK-2
F.	12958S	Short 2" Piston-30mm w/ O-Ring
G.	12959	2" Gaither Wrench
H.	12950	2" W 1.7 O-Ring

The #12937-A Valve Repair Kit, or BBVRK-2, is a new tool that lets the user repair/replace the piston/valve of the #12937-A. The BBVRK-2 is intended to extend the lifespan of the #12937-A by making the #12937-A fully serviceable. This kit saves the user precious time because the repairs can be done quickly and effectively in house.





GAITHER GB-5MA



GAITHER GB-5MA

RAR Bead Booster® Care

For best performance, please add silicone oil or air tool oil to the RAR Valve every 1~2 months by performing the following steps:

- 1.Remove the barrel.
- 2. Push the piston down.
- 3. Apply silicone oil or air tool oil to the upper part of the piston.
- 4. Apply the oil to the edge of the piston. (Black O-Ring)
- 5. Press the piston repeatedly until the oil flow into the interior of valve.





Care and Maintenance:

- Indoor use only
- Avoid this product under the sun or heat exposure
- Often maintenance can increase the time usage of the product
- · Use often, please maintenance weekly
- In order to avoid parts damage, do not use this product in the rain
- Recommend using silicone oil for maintaining piston,
 in order to avoid damage to the parts.

WARNING:

- COMPRESSED AIR IS DANGEROUS ALWAYS WEAR EYE AND EAR PROTECTION. ALWAYS FOLLOW THE INSTRUCTIONS GIVEN ABOVE.
- THE BEAD BOOSTER® IS A TOOL FOR THE TIRE INDUSTRY AND SHOULD NEVER BE USED OTHERWISE.
- The product should operate by professionals.
- Never allow the nozzle to point in the direction of a person
- Please vent the rest of air after use.
- Do not try to disassemble or modify the product.
- Please Keep away from children

Repair and Troubleshooting:

- Read the instructions and check BEAD BOOSTER® to see whether there are missing parts of damaged parts.
- If the Bead Booster can not be used, please contact the store for repair.

Note:













For other trouble shooting issues and maintenance suggestions for your new Bead Booster®, as well as tips for problematic tires, please log on to www.gaithertool.com

GAITHER NOTES

ABOUT US

Gaither Tool Company, Inc. founded in 1988, is an international organization committed to serving the tire and trucking industry. It invents and manufactures convenient tools and systems needed to service and maintain tires and wheel assemblies.

Gaither Tool Company, Inc. continually invests in research and development to bring to its customers the most effective tools in the business. It strives to improve efficiency and reduce costs for customers all over the world working in truck maintenance shops as well as on-the-road tire service providers, Bandag, Euromaster/Michelin, Bridgestone's First Stop. The United States Armed Forces... just to name a few.

Gaither supplies products to customers in over 100 countries, selling through exclusive and nonexclusive distributors. Gaither Tool Company, Inc. is headquartered in Jacksonville, Illinois, U.S.A. In 1997 it opened a branch office located in Roosendaal, Holland to better serve the European market. In 1999 that office was incorporated in Holland and Gaither Europe BV was started. Gaither's manufacturing plant and warehousing for International distribution is located in Taichung. Taiwan.

With a strategically placed location in both The United States and The Netherlands, we are able to serve the global industry



CONTACT US

gaithereurope.com

GAITHER EUROPE BV

Rechtzaad 6

4703 RC Roosendaal (Holland)

- t +31 (0) 165 554475
- f +31 (0) 165 391819
- e evd@gaithereurope.com



CHANGING THE WAY THE WORLD CHANGES TIRES