



*Gaither*<sup>®</sup>  
PROFESSIONAL EQUIPMENT

**REACHING  
FOR NEW  
HEIGHTS!**



INSTRUCTIONS FOR  
**GTABB-01**

**WARNUNG ! Bitte Wulst schmieren vor Anwendung !**

**IMPORTANT WARNING ! Lubricate bead area prior to usage !**

Bevor Sie mit dem Abdrücker arbeiten können müssen Sie den Abdrücker mit der Druckluft verbinden, bitte auf die korrekte Schlauchkupplung achten, Mindestdruck ca. 7 bar 120 l/m

*Before operating the Bead Breaker, connect the airline to the tool using the proper coupler. Minimum air pressure 100 psi*



Abdrücker am Felgenhorn ansetzen.

*Place the Wedge between the tire and wheel to begin.*



Abdrücker unbedingt fest greifen und Betätigungshebel leicht aktivieren ( laufrichtung beachten),  
Abdrücker zieht sich dann zwischen Reifenwulst und Felgenhorn, Abdrückerposition überprüfen.

*Hold the Bead Breaker firmly with both hands and use the trigger to operate. The Bead Breaker will first attach to the wheel prior to pressing on the tire.*



Betätigungshebel drücken – der Reifenwulst wird vom Felgenhorn gedrückt. Bitte Abdrücker mit Gegendruck in Position halten.

*The Bead Breaker now presses against the tire in order to break the bead loose from the wheel.*



Abdrückvorgang bei feststehendem Reifenwulst möglichst an mehreren Stellen vornehmen.

*It may be necessary to use the Bead Breaker in multiple areas of a tire depending on the size and difficulty.*



Um den Reifenabdrücker zu lösen muss der Umschalthebel gedrückt werden.

*Simply reverse the direction of operation in order to release the Bead Breaker from the wheel.*



Demo video : [www.gaihertool.com](http://www.gaihertool.com)

GAITHER

# NOTES



SMART  
TECHNO  
GROUP  
MARKETING

# ABOUT US

Gaither Tool Company, Inc. founded in 1988, is an international organization committed to serving the tire and trucking industry. It invents and manufactures convenient tools and systems needed to service and maintain tires and wheel assemblies.

Gaither Tool Company, Inc. continually invests in research and development to bring to its customers the most effective tools in the business. It strives to improve efficiency and reduce costs for customers all over the world working in truck maintenance shops as well as on-the-road tire service providers. Bandag, Euromaster/Michelin, Bridgestone's First Stop, The United States Armed Forces... just to name a few.

Gaither supplies products to customers in over 100 countries, selling through exclusive and nonexclusive distributors. Gaither Tool Company, Inc. is headquartered in Jacksonville, Illinois, U.S.A. In 1997 it opened a branch office located in Roosendaal, Holland to better serve the European market. In 1999 that office was incorporated in Holland and Gaither Europe BV was started. Gaither's manufacturing plant and warehousing for International distribution is located in Taichung, Taiwan.

With a strategically placed location in both The United States and The Netherlands, we are able to serve the global industry



## CONTACT US

[gaithereurope.com](http://gaithereurope.com)

## GAITHER EUROPE BV

Rechtzaad 6  
4703 RC Roosendaal (Holland)

† +31 (0) 165 554475

f +31 (0) 165 391819

e [evd@gaithereurope.com](mailto:evd@gaithereurope.com)



CHANGING THE WAY THE WORLD CHANGES TIRES